





Operation/Service Manual

Published: July 28, 2021

Innovation, Quality & Honesty

MDA-6 Door Pre Hanging Machine

With MDA-E Brickmold Machine



Proprietary Notice

This Manual is confidential and contains proprietary information and intellectual property of Inc., and is to be used solely by Customer as an operating manual for Inc. machines. Neither this Manual nor any of the information contained herein may be reproduced or disclosed under any circumstances without the express written permission of Inc. For authorization to copy this information, please call Customer Support at (800) 553-5825 or fax (707) 762-0485. Outside the U.S. and Canada, call (707) 762-7367.

Manual Name: MDA-6 and MDA-E Operation and Service Manual

Rev: 117-MV00.1, 117-MV100.0, 17-MV100.0

MDA-6 and MDA-E are trademarks of Incorporated.

Copyright 2021 Incorporated. All rights reserved.

All other products are trademarks or registered trademarks of their respective holders, all rights reserved. Reference to these products is not intended to imply affiliation with or sponsorship of Incorporated.

Contacting

Customer Service: For further information about this manual or other Incorporated products, contact the Customer Support Department

- Mailing address:

Customer Support Department
Incorporated
825 Petaluma Boulevard South
Petaluma, CA 94952

- Phone and Fax:

In the U.S and Canada, call (800) 553-5825 or fax (707) 762-0485
Outside the U.S. and Canada, call (707) 762-7367 or fax (707) 762-0485

- Business hours:

Technical Support:

6:00 AM to 4:00 PM Pacific Standard Time, Monday through Thursday

6:30 AM to 1:30 PM Pacific Standard Time, Friday

Parts & Service Sales:

6:30 AM to 4:00 PM Pacific Standard Time, Monday through Thursday

6:30 AM to 1:30 PM Pacific Standard Time, Friday

(Other sales related inquiries: <http://www.kvalinc.com>)

- Email: service@inc.com

Your Feedback is Welcome: To help us design products that make your job easier and your business more successful, we'd like to gain your perspective about your user experience with our product - that is, the manual, the machinery, the software, etc. What was easy or difficult to use or to learn? If you could change something about the design, what would it be? Please email your comments and suggestions for improvement to userexperience@inc.com. (**NOTE:** This is not a customer support email link. For that, please refer to the Customer Service contact information above.) Thank you!

<http://www.inc.com>



Table of Contents



Chapter 1 Introduction to the MDA-6 and MDA-E

| | |
|--|------|
| Overview of the MDA-6 and MDA-E | 1-2 |
| MDA-6..... | 1-2 |
| Available Options..... | 1-2 |
| MDA-E | 1-3 |
| Available Options..... | 1-3 |
| About this Manual | 1-4 |
| Safety First!..... | 1-5 |
| Safety Sheet Sign-Off Sheet..... | 1-5 |
| Safety Terminology of Labels..... | 1-5 |
| Safety Guidelines..... | 1-5 |
| Lockout-Tagout Guidelines | 1-9 |
| Follow the P-R-O-P-E-R lockout rule of thumb. | 1-9 |
| Lockout Tagout Procedure | 1-10 |
| Pre-Steps Before Lockout Tagout..... | 1-10 |
| Lockout Tagout Power | 1-10 |
| Lockout Tagout Air Supply | 1-11 |
| Start Maintenance..... | 1-11 |
| Post Maintenance Steps..... | 1-11 |
| Zero-Energy to Start-Up | 1-12 |
| Getting Help from Kval..... | 1-14 |
| Kval Return and Warranty Policy | 1-15 |
| Send the Item | 1-15 |
| Acceptance of Return | 1-15 |
| Refund Turnaround Time | 1-15 |
| Kval Errors..... | 1-15 |
| Customer Errors | 1-16 |
| Shipper Errors..... | 1-16 |
| Warranty Replacement Parts..... | 1-16 |
| Safety Sign-Off Sheet | 1-18 |
| A Note to the Operator..... | 1-18 |

Chapter 2 Operation of the MDA-6 and MDA-E

| | |
|--|-----|
| Operator's Tour | 2-2 |
| The Main Electrical Panel | 2-3 |
| About Limit Switches | 2-4 |
| Description of the Six Light Panel | 2-5 |



Table of Contents

| | |
|--|-------------|
| Powering Operations of the MDA-6 | 2-6 |
| How to Power Up the Machine | 2-6 |
| How to Power Down the Machine..... | 2-7 |
| Process to Operate the MDA-6..... | 2-8 |
| About the MDA-E Brickmold Machine | 2-9 |
| Overview of the MDA-E | 2-9 |
| Procedure to Process to Operate the MDA-E..... | 2-10 |

Chapter 4 Troubleshooting

| | |
|---|------------|
| About a Typical Contactor Control | 4-2 |
| About Contactor Troubleshooting | 4-3 |
| Limit Switches..... | 4-4 |
| Troubleshooting Electrical Problems | 4-5 |
| If the Power Stops During Normal Operation | 4-5 |
| Troubleshooting with the Status Light Panel | 4-7 |



CHAPTER 1 Introduction to the MDA-6 and MDA-E

This chapter provides an overview of the **Kval MDA-6** and the **Kval MDA-E** machines and important safety information to follow when operating the machine.

Chapter 1 at a Glance

TABLE 1- 1.

| Section Name | Summary | Page |
|--------------------------------|---|---------------------------|
| Safety! | IMPORTANT safety information is described in this section | Page 1-5 |
| Zero-Energy to Start-Up | Procedure to power up your machine for the first time. | Page 1-12 |
| Getting Help from KVAL | This section describes the method to contact the KVAL service center for help. The section includes how to get information from the specification plate to provide to KVAL, service center hours, and return procedures | Page 1-14 |
| Safety Sign-Off Sheet | A record to track operators that are trained on the machine. | Page 1-18 |



Overview of the MDA-6 and MDA-E

This section provides a general description of the MDA-6 and The MDA-E.

For detailed information about available options, please contact our **Kval Sales and Service** department. See our website (<https://kvalinc.com>) for contact information.

MDA-6

A door is rolled into the MDA-6 Pre-Hanging Machine on non-marking wheels. The door is then ready to have exterior casing applied as well as the finish packaging.

The table design supports doors ranging from 2'6" up to 3'0" on parallel rows of urethane wheels. The inner gap between the wheels also accepts doors with lights installed up to 25" wide at the outside of the light frame.

The assembled door unit is then hydraulically tilted to a near vertical position for easy off-loading by simply depressing a foot pedal.

Available Options

| Option | Title | Description |
|------------------|--------------------------------------|--|
| Option HD | Hydraulic Pump and Tilt Cylinder | Replaces the standard air cylinder tilt mechanism with a hydraulic pump and tilt cylinder operated with an two electric foot pedal for up and down. Much more heavy duty than the standard cylinder and required for 8'0" doors, or doors heavier than 100lbs including frame and glass. |
| Option B | Out-swing Door Support | Rollers and Delrin rails pivot up in seconds to transport inverted door frames from the light install station to the pivot table. Standard Acrobat requires out-swings to be lifted and carried between stations . |
| Option D | 8' Door Capacity' | Allows door units up to 8" width to be assembled and transferred. |
| Option H | Fold-Down Sill Support Plate | Support for Sill |
| Option I | Cylinder-Operated Width Adjust | Adjusts wheels to allow for 28-1/2" wide raised molding |
| Option K | Height Adjustable Sill Support Plate | Air cylinders provided to raise sill support plate up to 10" above floor when door unit is in vertical position. Includes ball-bearing wheels to enable easy transfer from MDA- |
| Option LV | 3 Phase Low Voltage | Kval Equipment is only manufactured at high voltage (460v). This option is for customers who require low voltage (208/230) for machinery operation |
| Option | Spare Parts Package | Please review with your KVAL consultant to determine your needs. |
| Option | Tooling and Lubricant | Please review with your KVAL consultant to determine your needs. |

MDA-E

The **MDA-E** is designed to make it easy to apply brickmold casing to the exterior of the door unit.


A door is rolled into the machine on non-marking wheels. For ergonomic reasons, the door is then lowered approximately 5". The operator then places the brickmold onto the exterior side of the unit and fastens it into place. The table is designed to support doors ranging from 2'6" up to 3'0" on parallel rows of urethane wheels. The inner gap between the wheels also accepts doors with lights installed up to 25" wide at the outside of the light frame. The assembled door unit is then rolled into the next work station for finish packaging.

Available Options

| Option | Title | Description |
|-----------------|---------------------------|---|
| Option Z | OutSwing Transfer Support | UHMW plastic rails mounted to the machine-frame to allow transference of outswing-units by gliding on rails opposed to dropping in-between standard rollers. Operator pulls the outswing door units through the conveyor, but will be able to do it without lifting up on the door. |
| Option C | Staple Gun Holster | Add desired number of holsters. |
| Option D | Screw Driver Holster | Add desired number of holsters. |

About this Manual

Operation and Service Manual includes the following:



| Chapter | Title | Description |
|---------|---------------------|---|
| 1 | Introduction | Descriptions of Machine Line and Safety Information. |
| 2 | Operation Interface | Descriptions of how to power machine line, and operator interface user screens. |
| 3 | Maintenance | Maintenance steps for the machine line |
| 4 | Troubleshooting | Troubleshooting tips and theory of operation. |

Safety First!



This machine is a powerful electro-mechanical motion control system. You should test your motion system for safety under all potential conditions. **Failure to do so can result in damage to equipment and/or serious injury to personnel.**

Safety Sheet Sign-Off Sheet

At the end of this chapter, there is a safety sign-off sheet. It lists personnel and machine safety criteria to understand before operating the machine. It is highly recommended that personnel operating, working on a machine meet the criteria listed in this sheet. It is recommended the sheet be signed and kept for records. See “Safety Sign-Off Sheet” on page 1-18.

Safety Terminology of Labels

In addition to the nameplate, KVAL machines may have other warning labels or decals that provide safety information to operators. Safety labels should be clearly visible to the operator and must be replaced if missing, damaged, or illegible.


There are three types of warning labels or decals:

- **DANGER** means if the danger is not avoided, it will cause death or serious injury.
- **WARNING** means if the warning is not heeded, it can cause death or serious injury.
- **CAUTION** means if the precaution is not taken, it may cause minor or moderate injury.

Safety Guidelines

In addition to the caution and warning labels affixed to this machine, follow the guidelines below to help ensure the safety of equipment and personnel.

Training



Ensure that all employees who operate this machine are aware of and adhere to all safety precautions posted on the machine and are trained to operate this machine in a safe manner.

Protective Gear




Never operate the machine without proper eye and ear protection.

When the Machine is ON



- **Never** reach hands beyond safety cage. Servo motors can unexpectedly move quickly.
- **Never** clear screws or hinges out of the machine while it is running.
- **Never** reach into the router area to retrieve a hinge. The router may still be running down after shut down.
- **Never** perform any maintenance unless machine is at zero state.
- **Never** clean the machine while it is running.
- **Never** walk away from the machine while it is running.

Compressed Air



The compressed air system connected to this machine should have a three-way air valve for shut-off and pressure relief.

All cylinders on machine are under high pressure and can be very dangerous when activated. Before performing any maintenance or repairs on this machine turn off the main air disconnect. **Lockout and tagout this connection.**


See “Lockout Tagout Procedure” on page 1-10.

Electrical



Electrical circuitry on this machine is protected by an approved lockable disconnect circuit. In addition to this equipment, you must install an approved disconnect for the electrical power supplying this machine.

Still has power in OFF position



When opening the cabinet you must first turn off the disconnect switch. When the cabinet door is open there is **still power on the top side of the disconnect switch**. Some machines are powered by more than one supply located at different locations. Before performing any repairs or maintenance, lockout and tagout **must be installed at all locations**

All maintenance and repairs to electrical circuitry should only be performed by a qualified electrician.

Before Conducting Maintenance



Prior to performing any maintenance, repairs, cleaning or when clearing jammed debris, you must disconnect, tag out, or lock out the electrical and air pressure systems. This should be done in accordance with applicable state and/or federal code requirements.

Laser Warnings

On some machines, laser indicators are used to set boundaries. Follow the manufacturers safety precautions.



Class 2

Lasers that emit visible radiation in the wavelength range from 400 nm to 700 nm where eye protection is normally afforded by aversion responses, including the blink reflex. This reaction may be expected to provide adequate protection under reasonably foreseeable conditions of operation, including the use of optical instruments for intrabeam viewing.
Reference 60825-1 Amend. 2 © IEC:2001(E), section 8.2.

Compliance with Codes and Regulations



KVAL advises that you request an on-site state safety review of your installation of this machine. This is to ensure conformance to any additional specific safety and health regulations which apply in your geographic area.

Other Hazard Control Action


Report a Hazard Before You Report an Accident



If you believe any part or operation of this machine is in violation of any health or safety regulation, **STOP** production. It is your responsibility to immediately protect your employees against any such hazard.

Additional detailed safety guidelines are included in the operating instructions of this manual. KVAL will be pleased to review with you any questions you may have regarding the safe operation of this machine

Follow Your Company's Safety Procedures



In addition to these safety guidelines. Your company should have on-site and machine specific safety procedures to follow.

Lockout-Tagout Guidelines

- Place a tag on all padlocks. On the tag, each operator must put their own name and date.
(These locks are only to be removed by the person who signs the tag)
- If more than one person is working on the machine, each additional person places a lock and tag on each disconnect.
- Only each operator may remove their own lock and tag.

Important: When many people are all working on the same machine you will need a multiple lockout device, such as the one shown here.



Follow the P-R-O-P-E-R lockout rule of thumb.

- P..... Process shutdown
- R Recognize energy type (electrical, pneumatic, mechanical, etc.)
- O..... OFF! Shut off all power sources and isolating devices
- P..... Place lock and tag
- E..... ENERGY: Release stored energy to a zero-energy state
- R Recheck controls and test to ensure they are in the “OFF” state

Lockout Tagout Procedure



This policy is required by OSHA regulation 1910.147 and Cal OSHA'S SB198 ruling of July 1991.

Use the following lockout procedure to secure this machine while it is powered down. During a lockout, you disconnect all power and shut off the air supply. Be sure to use the tagout guidelines noted below.

Pre-Steps Before Lockout Tagout




1. Evaluate the equipment to fully understand all energy sources (multiple electrical supplies, air supply and pressure, spring tension, weight shifts, etc.).
2. Inform all affected personnel of the eminent shutdown, and the duration of the shutdown.
3. Obtain locks, keys, and tags from your employer's lockout center.

Lockout Tagout Power

Power



4. Turn off machine. See Chapter 2 for power down and power up procedures.
5. Turn the disconnect switches on **ALL** electrical and frequency panels to the OFF position. Then push the red tab to pop it out. Place a padlock through the hole. Place your tag on the padlock, as per the tagout guidelines below. (see illustration below).



Turn Switch to the
OFF position



Insert Lock into hole.



Lock and Tag out

Note: When multiple people are working on the machine, each person needs to have a lock on the handle in the extra holes provided.

Lockout Tagout Air Supply



6. Turn all air valves to the OFF position and place a padlock through the hole (see illustration below).

NOTE: Place your tag on the padlock, as per the tagout guidelines.



Start Maintenance

7. Once the locks and tags are in place and all personnel are clear, attempt to operate the machine to ensure equipment will not operate.
8. Maintenance or repairs may started.

Post Maintenance Steps

9. After maintenance is completed, the person performing the work must ensure all tools, spare parts, test equipment, etc., are completely removed and that all guards and safety devices are installed.
10. Before removing the locks and tags, the person who attached them shall inspect the equipment to ensure that the machine will not be put in an unsafe condition when re-energized.
11. The lock and tag can now be removed (only by the person(s) who placed them), and the machine can be re-energized.
12. The tags must be destroyed and the locks and keys returned to the lockout center.

Zero-Energy to Start-Up

Starting the equipment properly is just as important as the lockout/tagout guidelines in terms of safety.

Start-up Guidelines

The following guidelines below should be followed to start the equipment.

Inspect

The equipment must be inspected for proper adjustment before starting equipment.

Clean Up

All materials and debris must be cleaned up. Any combustible materials or old parts used during repairs must be cleaned up and/or properly disposed of.

Replace Guards

Replace all equipment guards. If part of equipment cannot be properly adjusted after start-up with guard on, contact the KVAL Service team. See “Getting Help from Kval” on page 1-14.

Check Controls

Confirm that all switches are in the “OFF” position. Please be advised that some components of the machine may start automatically when energy is restored.

Remove Locks

Each operator must remove his or her own lock and tag. This will ensure that all operators are in a safe place when the equipment is started.

Perform Visual Checks

If the equipment is too large to see all around it, station personnel around the area and sound the personnel alarm before starting the equipment. If your operation is more complex, your company’s comprehensive safety procedure may involve additional steps. You will need to ask your supervisor about these procedures. The company’s lockout procedure should be posted at each machine. On larger or long-term maintenance or installation projects, the company’s procedures must be explained to all new operators and a copy of the company’s procedures should be posted on-site for the duration of the work.

The Company’s procedures should also include provisions for safely handling shift changes and changes in operators or new operators. Comprehensive lockout/tagout may use a gang box or other system to ensure that locks are secure and not removed without authorization.



Remember, lockout/tagout procedures work because you are the only one with the key to your lock. Proper lockout/tagout can save lives, limbs, and money. Help make your work environment safe for you and your fellow workers. Be sure to follow the P-R-O-P-E-R lockout/tagout procedures, and that those around you do also.

Close the Cage Gate

Verify all cage gates are securely closed. Ensure all safety protocols are in effect.

Getting Help from Kval

Before you seek help, first try the troubleshooting procedures. Follow the procedures below.

If you are unable to resolve the problem:


1. Locate the machine's Specification Plate and record the serial number, 3 phase volts, electrical print number, and air print number.



Air Driven Machines



**Pre -2019 Machines,
look for the brass plate.**



2. Contact our customer support team:

- In the U.S and Canada, call (800) 553-5825 or fax (707) 762-0485
- Outside the U.S. and Canada, call (707) 762-7367 or fax (707) 762-0485
- Email address is service@Kvalinc.com
- Hours:

6:00 AM to 4:00 PM Pacific Standard Time, Monday through Thursday

6:30 AM to 1:30 PM Pacific Standard Time, Friday



Kval Return and Warranty Policy

Kval's goal is to provide customers with high quality products. If, for any reason, you are not completely satisfied with your purchase, please contact us at:

Email: parts@kvalinc.com

Phone: +1 (800) 553-5825

- **Restocking Fee:** Returned manufactured products are subject to a 15% restocking fee and applied when **Kval** incurs additional costs due to customer ordering error, or manufactured parts ordered for a service related issue and subsequently returned.
- **Shipping Fees:** The customer is responsible for charges required to ship return items back to **Kval**.
- **Mark the Item:** With a marking pen, clearly write on the outside of the carton RMA #

Send the Item

Return the item to this address:

Kval Inc.
RMA# _____ : Kval Parts
825 Petaluma Blvd South
Petaluma, CA 94952
USA

Acceptance of Return

We can only accept items for a return if they are still in their original packaging and in undamaged, resalable condition.

Returns are accepted within 45 days of purchase and with an RMA number issued by Kval Inc. Returns after 45 days of purchase or without a Kval Inc. issued RMA number will not be accepted.

Refund Turnaround Time

Refunds usually take from 3 to 10 business days to process. The refund will be issued via the billing method the customer used to purchase the product.

Kval Errors

If the item must be returned because we shipped the wrong item, please call our customer service line immediately and arrange for re-shipment of the correct product. Kval Customer Service will arrange for UPS to pick up the incorrect shipment at our expense.



Customer Errors

If the item is to be returned due to customer ordering error, the customer must return the item to Kval or the shipper of origin at its expense. A 15% restocking fee may apply to manufactured products that are incorrectly ordered by the customer, or if the manufactured part is returned due to a service related inquiry.

Shipper Errors

Kval recommends the customer insure return shipments if there is any doubt that the product will be accepted in saleable condition at the Kval warehouse. Occasionally, UPS or FedEx will damage a package, lose a shipment, or send an item to the wrong address. Please insure return shipments.

Warranty Replacement Parts

Kval provides a warranty to products that are deemed defective. Within 30 days of discovery of said defect, please notify Kval, but no more than one (1) year after delivery will the product be covered under Warranty. The repair, replacement, or payment in the manner described above shall be the exclusive remedy of Buyer for breach of Kval's warranty or for claims based upon failure of or defect in the products regardless of when the failure or defect arises, and whether a claim, however described, is based upon contract, warranty, indemnity, tort/extra contractual liability including negligence, strict liability or otherwise.

Normal wear and tear, and deterioration during use shall not constitute a defect in material or manufacture under this limited warranty.

Note: In no event is Kval liable for any consequential, incidental, special or indirect damages whatsoever (including without limitation personal injury, property damage, lost profits or other economic injury) even if Kval has been advised of the possibility of such damages, or any damages or loss attributable to incorrect use or abuse of the products, including but not limited to, inadequate or improper maintenance or unauthorized alteration.

- What is the extent of the failure/reason for return? What are the relevant error messages or error codes?
- How long did it operate?
- Did any other items fail at the same time?
- What was happening when the unit failed (e.g., installing the unit, cycling power, starting other equipment, etc.)?
- How was the product configured (in detail)?
- Which, if any, cables were modified and how?
- With what equipment is the unit interfaced?



Page Intentionally Left Blank



Safety Sign-Off Sheet

Machine Model Number: _____

A Note to the Operator

This machine can help you be highly productive only if you understand how to use it properly and follow the safe operating practices described in this document and the machine's manual. If you do not understand the machine's proper operation or ignore the safe operating practices, this machine can hurt or kill you. It's in your best interest to safely and properly operate this machine.

Personnel Safety Concerns:

- I have been properly trained in the operation of this machine.
- I will always wear ear protection when operating this machine.
- I will always wear eye protection when operating this machine.
- I will never wear loose clothing or gloves when operating this machine.
- I will watch out for other people. Make sure everyone is clear of this machine before operation.
- I will always follow my company's safety procedures. I have read and understand these guidelines.

Machine Safety Concerns:

- I have been given a tour of the machine and understand all the safety labels, E-Stops and the actions to take in case of an emergency.
- I will make sure all guards are in place before operation
- I will turn off the compressed air, before loading hardware (staples, screws, etc)
- I will turn off the electrical power, for setup
- If the machine should operate in an unexpected manner stop production I will immediately and notify a manager, a supervisor, or a qualified service technician.

I have read and understand this document and agree to operate this machine in a safe manner as described above.

Employee

Name (print): _____ Signature: _____ Date: ____/____/____

Supervisor/Safety Officer/Trainer

Name (print): _____ Signature: _____ Date: ____/____/____

Note: It is recommended you make a copy of this sheet for new operators. If a copy is needed, you may download a PDF at the KVAL website (<http://www.kvalinc.com>). You may also contact our Service Department at (800) 553-5825 or email at service@kvalinc.com.



CHAPTER 2 Operation of the MDA-6 and MDA-E

This chapter describes components, assemblies, and the user interface of the **Kval MDA-6** and **Kval MDA-E**. The content is geared to help operators understand the basic operation of the machine.


Chapter 2 at a Glance

| Section Name | Summary | Page |
|---------------------|--|--------------------------|
| About the MDA-6 | Descriptions of the operation of the parts and assemblies of the machine | Page 2-2 |
| Powering Operations | Descriptions of power up, power down, homing, and emergency stops | Page 2-6 |
| About the MDA-E | Description of the operation of the MDA-E | Page 2-9 |

Operator's Tour

This section describes controls and assemblies on the **MDA-6**.

Controls: Controls are located at this end to activate and deactivate the Pop-ups



Option I: Width Cylinders Locations

FIGURE 2- 1.

The Main Electrical Panel

Figure 2- 2 below, is an overview of the location of assemblies in the panel

Warning: High Voltage is present in this panel at the top of the Three Phase Input **even with the disconnect off**. If working on the panel, follow safety protocol as described in Chapter 1.




FIGURE 2- 2. Overview of Main Electrical Panel and High Frequency Panel


About Limit Switches

Limit switches are mechanically tripped to identify the maximum and minimum limit of the lift.

The **Limit Switch** is activated by an assembly moving a switch arm.

- Depending on the model of limit switch, the amount of “pre-travel” (amount of movement from the arms resting position) is either 5 or 20 degrees before the limit switch actuates (Clicks).

Switch Arm



Description of the Six Light Panel

The six lights on this panel indicate the status of the MDA-6 system.


The Sequence that the lights activate is as follows:

1. Control Power
2. Overload Relay
3. E-Stop
4. Stop
5. Start
6. 24VDC

Control Power – light illuminates when the Control Transformer is pulled out and the power is working on secondary side-of transformer

Overload Relay –
The overload circuit is working when light is on

E-Stop – The back gate is closed and Frame E-stop is not activated when this light is on.



Stop – This light will be on if Machine Stop button is deactivated.

Start – This light will be on once the Machine Start button is pressed and the ACR Relay is latched.

24VDC – light comes on once the ACR is latch and the 24VDC power Supply is working

Powering Operations of the MDA-6

This section describes how to power up and to power down the **MDA-6**.

Powering up the system includes:

- Applying power to the entire system
- Starting the Control Circuit

Powering down the system includes:

- Shutting down the control power
- Removing power from the entire system


How to Power Up the Machine

1. Ensure factory air is applied to machine and main air supply is turned on.
2. Make sure the electrical disconnect the electrical cabinet is turned to the ON position.
3. Pull the green **CONTROL TRANSFORMER** button out to the ON position. It should light up.
4. Push the green **START MACHINE** button to initialize the machine.
5. The Six Lights will turn-on.

Step 2: Pull Out
Control Trans-
former Button

Step 3: Press
The Green Start
Button

Step 1: Turn On
Disconnect



Step 4: All six
lights are ON

How to Power Down the Machine

1. Push the **Stop** button, located on the Electrical Panel.
2. Push the green **CONTROL TRANSFORMER** switch to the OFF position.
3. KVAL also recommends that you turn the disconnect switch on the electrical cabinet to OFF; this helps reduce possible damage resulting from power surges from electrical storms.



Process to Operate the MDA-6

Pneumatic control switches are located at the front of the machine.

Note: If processing a door with raised moulding, press switches to engage the cylinders. (Optional, MDA-6 may not have this feature)

Width cylinder controls



1. Roll the door into the machine.
2. Operate the foot switch to bring the door to the vertical position.
3. Remove door to start the next process step.




About the MDA-E Brickmold Machine

The **MDA-E** is designed to apply brickmold casing to the exterior of the door unit. The table is designed to support doors ranging from 2'6" up to 3'0" on parallel rows of urethane wheels. The inner gap between the wheels also accepts doors with lights installed up to 25" wide at the outside of the light frame.

Note: The **MDA-E** is a fully pneumatic operated machine. No electrical wiring is needed.

Overview of the MDA-E





Procedure to Process to Operate the MDA-E

1. Roll a door into the machine on non-marking wheels.
2. Operate the pneumatic switch once to lower the door (Approximately 5").
3. Place the brickmold onto the exterior side of the unit and fasten it into place.
4. Operate the pneumatic switch again to raise the door.
5. Roll the door to the next work station for finish packaging.

CH-2
Operation



CHAPTER 3 Maintenance of the MDA-6 and MDA-E

This chapter describes preventative maintenance steps for **Kval MDA-6** and **Kval MDA-E**. The content is geared to guide technicians to keep a regular maintenance schedule for your **Kval** machine. Keeping your **Kval** machine maintained is an important piece for successful operation of your door production process.

Chapter 3 at a Glance

| Maintenance Schedule | <p>This section describes the assemblies to schedule for maintenance.</p> <ul style="list-style-type: none">• Daily• Weekly 5• Six Month Checkups | Page 3-2 |
|---------------------------------|---|--------------------------|
| Lubrication Requirements | <p>This section describes the lubrication requirements for the machine, including types of lube to use. This section includes:</p> <ul style="list-style-type: none">• Linear Bearings, Flange Bearing, and Pillow Blocks• Gear Motor Lubrication Requirements• Ball Screws• Description of Air Input System• Adjusting the Air Line Lubricator• Priming the Air Line Lubricator | Page 3-4 |



Maintenance Schedule

Kval recommends the following maintenance schedule to ensure that the machine operates properly.

Daily, Monthly, Six Month Maintenance

| Daily Preventive Maintenance | |
|------------------------------|---|
| Op | Operation Description |
| Clean | Blow off dust from the entire machine. Wipe down the outside of the machine with a clean dry cloth. |
| Check | Check tooling for wear. |
| Clean | Wipe off the photo eyes with a clean dry cloth, and check to ensure that all fastening nuts are snug. |
| Check | Check the air pressure to make sure it is set at 80 psi to 100 psi. |
| Clean | Empty any Dust Collection Units. |
| Check | Check for obstructed flow when excessive sawdust appears. |
| Check | Check the air filter water trap. Empty if full. |

| Weekly Preventive Maintenance | |
|-------------------------------|--|
| Op | Operation Description |
| Check | Check the machine for smooth motion through a complete door cycle |
| Clean | Clean linear bearings and the chrome shaft with a clean dry cloth, then lubricate. |
| Check | Check all air lines & electrical wiring for kinks or rubbing. |
| LUBE | Refill lubricator with an ISO 32 standard hydraulic oil (KVAL part# SYSLUBG) |

| Six Month Preventive Maintenance | |
|----------------------------------|--|
| Op | Operation Description |
| Clean | Wash filter and lubricator bowls with soapy water. |
| LUBE | Grease all bearings and tighten all bolts. Access to some grease fittings is difficult and will require a special needle point grease tip (supplied with your system). |
| Clean | Clean and lubricate all slides and cylinder rods with dry silicone spray. |
| Tighten | Tighten all bolts. |
| Back-up | Backup computer software. |
| LUBE | Lubricate linear bearings and chrome shafts with silicone. |

Lubrication Schedule

Kval recommends the following lubrication schedule to ensure that the machine operates properly.

| Type of Assembly | Recommended Schedule | Recommended Lubrication Type |
|-----------------------------|---|--|
| Linear Bearing | Every 250 Hours of Machine Operation | Dura-Lith Grease (KVAL P/N Lube EP-2) |
| Pillow Block Bearing | | |
| Flange Block Bearing | | |
| Ball Screw | Every 80 Hours of Machine Operation | |
| Idler Shafts (Pulley) | Monthly | |
| Tapered Bearing | One Pump 4 Times a Year | |
| Air Line Lubricator | One drop of oil every 2 or 3 cycles Check the lines every week to two weeks Note: Some CNC Machines drop every 5-10 cycles. | Either lubricant listed below is approved to use. <ul style="list-style-type: none"> • KVAL P/N SYSLUBG • Chevron AW Hydraulic Oil 32 • G-C lubricants light AW R&O • Mobile DTE 24 • Shell Tellus32 • Gulf Harmony 32 |

Typical Lucubration Kit

Kval Part Number: LUBEKIT



Lubrication Requirements

This section describes the parts of the machine that require periodic lubrication, and specifies the lubricants. In addition, it explains how to maintain the lubrication systems on the machine.

If the bearing is equipped with a grease fitting (Zerk Fitting).

The Zerk fitting is basically a valve that opens under pressure to allow lubricant to pass through a channel and be forced into the voids of the bearing. When the pressure stops, the ball returns to its closed position. The ball excludes dirt and functions as a check valve to prevent grease escaping back out of the fitting.

The ball is almost flush with the surface of the fitting so that it can be wiped clean to reduce the amount of debris carried with the grease into the bearing.

Note: Bearings without grease fittings have been pre-lubricated at the factory and do not require further lubrication.

Note: Clean excess grease to avoid contact with feed belts, clamping areas, or the door.




Zerk Fitting



Pillow Block Bearing Housings

A pillow block is any mounted bearing where the mounted shaft is in a parallel plane to the mounting surface, and perpendicular to the center line of the mounting holes, as compared to different types of flange blocks or flange units. The type of rolling element defines the type of pillow block.


Opened Pillow Block



Closed Pillow Block



Hub Style



Greasing

Approximately 1 Gram (one pump from grease gun) of Dura-Lith Grease (KVAL P/N: Lube EP-2).
Every 250 hours of operation.

FIGURE 3-2. Pillow Block Bearings

Flange Bearing Housings

A flange bearing is designed to aid in mounting and positioning. The lip of the flange helps center and align the bearing.

Flanges are also used with bearings on external housings used to mount a bearing unit. A mounted bearing unit acts as a system to position the bearing securely for reliable operation.





FIGURE 3-3. Flange Bearings

Lubrication Points MDA-6

Identify zerk fittings and apply EP-2 grease. **Lockout/Tagout** before maintenance. For recommended greasing schedule, see “[Lubrication Schedule](#)” on page 3-3.

Note: Some bearings may be difficult to get access to. Use an extender to reach tight areas.

1. Perform **Lockout/Tagout**.
2. Identify zerk fittings and apply EP-2 grease. (See Figure 3-4)
3. After lubrication is completed, reverse **Lockout/Tagout**.



Shaft Assembly
(X2)

FIGURE 3-4. MDA-6 Lubrication Points

Lubrication Points MDA-E

Identify zerk fittings and apply EP-2 grease. **Lockout/Tagout** before maintenance. For recommended greasing schedule, see “[Lubrication Schedule](#)” on page 3-3.

Note: Some bearings may be difficult to get access to. Use an extender to reach tight areas.

1. Perform **Lockout/Tagout**.
2. Identify zerk fittings and apply EP-2 grease. (See Figure 3-4)
3. After lubrication is completed, reverse **Lockout/Tagout**.




FIGURE 3- 5. MDA-E Lubrication Points

Description of Air Input System

There are two types of air inputs on **Kval** machinery. Not all machines have lubricator option installed. Check your machine or Air prints to verify installation.

Air Input with Lubrication

The air input system takes in shop air and supplies clean dry air (CDA) and lubricated air to the machine. The clean dry air is diverted to blow off nozzles. The lubricator, located after the CDA filters, delivers the lubricated air to valve banks and air cylinders.




FIGURE 3-6. Typical Air Line Filter and Lubrication System

Adjusting the Air Line Lubricator

Using the knob on the top of the lubricator, adjust until one drop per every other cycle is used (as observed through sight glass.)

(Sight Glass). When the oiler has run dry, open the knob all the way until flow begins. Once you have a steady flow, tighten knob back down until you have one drop per every other cycle.

Drop will form at end of cane shaped tube visible inside glass.

Top of Lubricator



Priming the Air Line Lubricator

New and used machinery run out of oil from time to time. It is a good practice to check your machine lubricator to insure that it is putting the proper dose of oil in the air lines. Usually 1 drop of oil every other cycle is a good rule of thumb. The approved list of oil for lubricators is as follows:

- KVAL P/N SYSLUBG
- Chevron AW Hydraulic Oil 32
- G-C lubricants light AW R&O
- Mobile DTE 24
- Shell Tellus32
- Gulf Harmony 32

To prime the lubricator, find an air line on the carriage section of the machine that is energized, and disconnect it, allowing the air stream to bleed air pressure away from any persons. Direct the air stream at the machine so you can see when there is an oily film blowing out of the air hose. Repeat this same procedure for the back section and other trouble areas.

It is recommended to check the lines every week to two weeks.

Air Line Without Lubricator

The air input system takes in shop air and supplies clean dry air (CDA).




FIGURE 3-7. Air Filter without Lubricator





CHAPTER 4 Troubleshooting

This chapter describes troubleshooting steps to help technicians solve issues that may occur with your KVAL machine. If help is needed, call or contact our KVAL Service team at (800) 553-5825 or <http://www.kvalinc.com>.

Note:

Refer to the Air and Electrical drawings provided with delivery of the machine. The drawings are normally located in the Electrical Panel. If copies are unavailable, contact the KVAL Service Department. Have drawings numbers, model number, and serial number of machine readily available.

Chapter 4 at a Glance

| Section Name | Summary | Page |
|-------------------------------------|--|--------------------------|
| About Contactor Control | Describes a typical contactor control circuit. | Page 4-2 |
| Limit Switches | Troubleshooting Limit Switches | Page 4-4 |
| Troubleshooting Electrical Problems | Includes voltages in the electrical panels, using the Status Light panel to troubleshoot | Page 4-5 |




About a Typical Contactor Control

Unlike general-purpose relays, contactors are designed to be directly connected to high-current load devices. Contactors are designed to control and suppress the arc produced when interrupting heavy motor currents. The figure below shows a block diagram of a typical contactor circuit with typical voltages. Thermal overload relays are commonly attached to the contactor. They offer protection for motors in the event of overload or phase failure. A Reset button is included to clear an error in the relay.



High Voltage may cause personnel **injury or death**. Troubleshooting checks *must* be performed by a Qualified Electrical Technician.



Note: Pre-2006 machines may not contain the 24 Volt relay. 120 Vac is directly fed into the Control Coil. Check the input circuitry to the Control Coil for 120 Vac.

Schematic Drawing of Contactor and Thermal Overload




FIGURE 4- 2. Block Diagram of a Common Contactor Circuit




FIGURE 4- 3. Contactor Bank

About Contactor Troubleshooting

The Thermal Overload Circuit opens the motor circuit when current draw causes the motor to run too hot. The overload limits are set at the factory, do not adjust the limits.


The overloads are normally in series, therefore if one trips, all on that circuit stop working.

Use the Six Light panel as a trigger to check the circuit. [See “Troubleshooting with the Status Light Panel” on page 4-7 .](#)

1. Open the Main Electrical Cabinet to find the Contactor /Thermal Overload Assembly
2. Press each ‘Green’ Reset button on the Thermal Overload. An audible click will be heard on the tripped circuit. (Take note of tripped circuit.)
3. Once the overloads are reset, verify LED’s are on.
4. Rerun the machine and verify that motor runs without tripping the circuit.
5. If the same overload keeps tripping, verify condition.
6. Follow circuit path using the E-Drawing as a reference.
 - a.Common issues: Check for bad wire, bad motor, or if load is too great for current draw.

Limit Switches

If a machine suddenly stops in mid cycle check the limit switches, a worn limit switch arm or a mis-adjusted limit switch is more than likely the cause. Depending on the model of limit switch you receive the amount of “pre-travel” (amount of movement from the arms resting position) is either 5 or 20 degrees before the limit switch actuates (Clicks). If the arm is moved to the full extents of its travel and you do not here the limit switch “Click”, the switch needs to be adjusted here is how you adjust it follow the following drawings.



Troubleshooting Electrical Problems

NOTE: Refer to Air and Electrical Schematics provided with delivery of the machine. Schematics are located in the Electrical Panel. If copies are unavailable, contact the KVAL Service Department. Have model number and serial number of machine readily available.

Warning The following checks require the electrical panel to be energized. These troubleshooting checks *must* be performed by a **Qualified Electrical Technician**.



The electrical component systems are designed to expedite the troubleshooting process and minimize “down time”. In general, component systems have the input or feed functions at the top. Output or load functions are positioned at the bottom. Most two-voltage electrical panels are designed with the LOW VOLTAGES on the LEFT, and the HIGH VOLTAGES on the RIGHT. The majority of the system components are labeled with numbers that correspond with the electrical prints included in the electrical box door.

Computer controlled machines have signals on the computer that light up when the input or output functions are energized, respectively. Computer controlled as well as non-computer controlled machines have white 120V control power terminal strips. This will indicate power supply from the respective circuits.

PLC controllers also have lights on them for the input and output functions. You can easily find out which circuits are failing by watching the lights turn on or off. Compare the lights on the IDEC or Beckhoff controllers to the electrical print to determine what systems are being affected.


If the Power Stops During Normal Operation

1. Check that the input power disconnect switch is not turned off.
2. Check that all of the emergency stop buttons are in the normal position.
3. Check the Six Lights on the Electrical Panel. See “Troubleshooting with the Status Light Panel” on page 4-7.

Lockout and Tagout the main power source.

1. Turn the panel disconnect switch in the off position, open the electrical panel door.
2. Observe the disconnect switches. Look for loose or broken wires at the disconnect then at all of the components.
3. Check for continuity of all fuses with an OHM meter. (Fuses need to be removed from the bottom side of the fuse holder before measuring the fuses)

4. With the power off, check for motor overloads by pressing each reset button (usually at the bottom of the panel) in SEQUENCE. If one is tripped there will be a slight resistance to touch and a “click” sound as it is reset.



Thermal Overload Relay

Check for Tripped Circuits

1. Remove lock and tag outs on the main power sources.
2. Manually close disconnect sensors and energize the control circuit or transformer with its respective sensor. Check the Status Light Panel,. If all lights are observed, there are no overloads or emergency stops tripped.

Note: Most electrical problems are related to mechanical malfunction (e.g., stuck motors, jammed chain, blocked photo sensors etc.)

Note: If a solenoid valve is suspected, and not cleared in the air checks section, it can be electrically jumped to check operation.

Troubleshooting with the Status Light Panel

The Status Light Panel is located on the Electrical Panel. All six lights are illuminated when the system is in proper working order. The lights turn on in a sequence and will stop at the point where a fault is first detected.

The sequence that the lights turn on are as follows:

1. Control Power (Amber)
2. Overload Relay (Amber)
3. E-Stop (Amber)
4. Stop (Amber)
5. Start (Amber)
6. 24VDC (Green)



If one or more lights are OFF, follow the process below to isolate the cause.

NOTE: Be sure to proceed down the table, starting with the CONTROL POWER light.

STEP 1:Control Power (Amber). If light is OFF go to item **A** on [Page 4-8](#).

STEP 2:Overload Relay (Amber) If light is OFF go to item **B** on [Page 4-9](#).

STEP 3:E-Stop (Amber) If light is OFF go to item **C** on [Page 4-9](#).

STEP 4: Stop (Amber) If light is OFF go to item **D** on [Page 4-9](#).

STEP 5: Start (Amber) If light is OFF go to item **E** on [Page 4-10](#).

STEP 6: 24VDC (Green light is OFF go to item **F** on [Page 4-10](#).




Control Power Light OFF

1. Check if the Control Transformer button is pulled out.



2. Is the Disconnect Switch on the main electrical cabinet set to ON?


Switch



3. Is there 208, 220, 440, or 575 VAC to the top side (input) of the Control Transformer? If not, check the fuses at the Fuse Block, and the contacts on the Control Transformer button on the switch panel.

Typical Control Transformer

Input
High Vac



Output
120 Vac

4. Is there 120 VAC between #1 & #2 on the 120 VAC Terminal Strip? If not, check the fuse on the output side of the Control Transformer. If fuse is good, check power coming out of Control Transformer.
5. If no power on the output side, and there is power going into the top of the Control Transformer, replace the Control Transformer.
6. If there is power at the Control Transformer, check the wiring of the black and white wire going from the Control Transformer to the 120 VAC Terminal Strip.
7. If there is no power between #1 and #2, check the secondary side of the transformer.
 - a. Check between X1 and X2. If no power is measured it is a bad transformer.
 - b. If there is power at X1 and X2, check the other side of the fuse. If now power, replace the fuse.

B

Overload Relay Light OFF

1. Check Motor Overload Circuits
2. With power on, check the trip indicator LED on the overload. If indicator is orange, press the Reset Button to reset the overload circuit. Retest the Machine.



Contactors

Overload Relays



Trip Indicator

Test or Stop

Factory Set Current
Rating Adjust
Reset Button. Fac-
tory set on the "H"
Setting.


 Troubleshoot
CH-4

C

E-Stop Light OFF

Check if any E-Stop buttons are pulled out.

NOTE: Location and quantity of E-Stop buttons varies depending on customer need. Typical locations for E-Stop buttons are near the Rear Access Gate and near the Tool Changer Access Gate



D

Stop Light OFF

Check for 120 VAC between #2 and #4. If there is voltage, press the Start button. If no voltage, check the Stop button to make sure it is all the way out and not stuck in, then check the contact to make sure it is closed. If still no voltage, check the wiring.



E

Start Light OFF

If the Start light remains unlit, push in the Start button and hold it in while a second person checks for voltage between #2 and #5. If there is 120 VAC, replace the ACR relay. If there is no voltage while the button is held in, check the wiring or the contact on the **Start** button.



F

24VDC Light OFF

First isolate the power supply. Check between DC+ and DC- for 24VDC. If no DC voltage, disconnect the output (V+) wire from the 24VDC power supply and check for DC voltage where those wires were disconnected.




If no voltage:

Check the input side for 120 VAC. If no 120 VAC, check the fuse. If there is 120 VAC and no 24VDC, replace the 24VDC Power Supply.

Input 120 VAC

Output 24 VDC



If there is 24VDC:

Reconnect the (V+) wire to the 24VDC power supply.

Trace the output wire to the DC terminal block.

Disconnect all (+ 24V positive) wires from the + DC from the DC terminal block except the + output wire from the + 24VDC power supply.

Check for +24VDC at between any -DC and +DC terminal on the DC Terminal block.

Reinstall the (+ 24V positive) wires one by one, checking for +24VDC after installing each. If at any point no voltage is found trace the last installed wire and check for shorts.

C

- contact information 2
- control panel light
 - not on? troubleshoot 8
- control power indicator light description 5
- control transformer switch
 - power up 6, 7
- customer service 2

E

- electrical panel 3
- e-stop light
 - description 5

I

- in-feed section
 - key assemblies 2

L

- lockout and tagout Guidelines 12
- lockout procedure 10

O

- operator's tour
 - top view 2
- overload relay light description 5

P

- PLC
 - location in main electrical panel 3
- power
 - lock out procedure 10
- power up
 - troubleshooting 5
- powering
 - up and down machine 6

R

- RKG-3 Entry Door 9

S

- safety guidelines 5
- Safety Sign Off Sheet
 - Safety Concerns 18
- sensors
 - types 4
- six light panel
 - description 5

- sequence list 5
- start light
 - description 10
- start light description 5
- start machine button
 - power up 6
- status light panel
 - description 7
 - use as troubleshooting key 7
- stop light description 5

T

- tagout procedure 10
- troubleshooting
 - using status lights 7

Z

- zero-energy start-up
 - clean up 12
 - inspect 12



Index



Notes:



Index



Notes:



<http://www.kvalinc.com>



Contacting KVAL

Phone and Fax:

In the U.S and Canada, call (800) 553-5825 or fax
(707) 762-0485

Outside the U.S. and Canada, call (707) 762-7367
or fax (707) 762-0485

Email: service@kvalinc.com

<http://www.kvalinc.com>

Customer Service

Mailing address:

Customer Support Department

Kval Incorporated

825 Petaluma Boulevard South

Petaluma, CA 94952
